

	PROCEDURE 8.007 Wireless Transmitter Pairing Instructions		APPROVALS Approvals on File <hr/> <hr/> <hr/>
	Revision 001	Effective Date: 3/15/2022	
WHEN PRINTED, THIS DOCUMENT IS UNCONTROLLED.			

1.0 PURPOSE/SCOPE:

- The purpose of this procedure is to pair transmitters that **DO NOT** have a yellow dot on the back cover and for transmitters that **DO** have a yellow dot on the back cover
- The handheld Transmitter(s) and hoist receivers must be “paired” to work with each other. This operation is necessary anytime either device is replaced.

2.0 PROCEDURE:

To configure a new transmitter to work with an existing hoist receiver, follow these steps:

- 2.1** Disconnect (unplug) the power supply to the lift
- 2.2** Remove the batteries from the transmitter
- 2.3** Follow the steps below if you have **Model: 21-2S-WD Transmitter** ***THAT DOES NOT*** have a yellow dot on the back cover. If your transmitter HAS a yellow dot, please skip down to step 2.4
 - 2.3.1** Turn the green knob to off
 - 2.3.2** Press and **hold both** the “**STOP**” and “**up**” buttons while inserting the batteries. Wait for the red LED light of the transmitter to begin to flash rapidly. Then release the buttons.
 - 2.3.3** After a few seconds, the red LED light of the transmitter will change from a fast flash to a slow flash
 - 2.3.4** Plug in the lift
 - 2.3.5** Press the “**DOWN**” button to complete the coding operation
 - 2.3.6** Turn the green knob on the transmitter to “**ON**” and press the START button
 - 2.3.6.1** (Transmitters with a **BD** in the serial number on the back will need to have the **START BUTTON** pressed for 10 seconds)
 - 2.3.7** Test the DOWN and UP buttons

The lift is now operational. (Check that the battery compartment is secured)

2.4 Follow the steps below if you have **Model: 21-2S-WD Transmitter** **THAT HAS** a yellow dot on the back cover

2.4.1 Turn the green knob to off

2.4.2 Press and **hold both** the **“STOP”** and **“UP”** buttons while inserting the batteries. Wait for the red LED light of the transmitter to begin to flash rapidly. Then release the buttons

2.4.3 After a few seconds, the red LED light of the transmitter will change from a fast flash to a slow flash

2.4.4 Plug in the lift

2.4.5 Press the **“UP”** button to complete the coding operation

2.4.6 Turn the green knob on the transmitter to **“ON”** and press the **START BUTTON**

2.4.7 Test the DOWN and UP buttons

The lift is now operational. (Check that the battery compartment is secured)

END OF PROCEDURE